



ASSEMBLY INSTRUCTION

MODEL : HM 2221.01

DESC : SHOE CABINET

HARDWARE	A	A5	B	C	D	E1	E2	F	G	H	I	L											
	 A1 MINIFIX 5654+5546	 A2 MINIFIX CAP	 A3 MINIFIX CAP	 L KEY	 WOOD DOWEL M8 X 25MM	 CSK CAP WOOD M6X50MM	 CB SCREW M3.5X16MM	 CB SCREW M3X12MM	 P/H SCREW M4X20MM	 STOPPER 2 PIN	 NAIL 5/8	 H1 HANDLE 128-12	 H2 CB SCREW M4X25MM	 I1 2 TRAY SHOE CABINET -195 (LEFT)	 I2 2 TRAY SHOE CABINET -195 (RIGHT)	 I3 TRAY -NUT JOINER	 I4 TRAY -NUT JOINER	 L 5038 PVC LEG					
	6 SETS	1	10	4	16	36	6	6	24	3	6	3	3	6	6	4							

PART LIST

STEP 1

STEP 2

STEP 3

STEP 4

STEP 5

STEP 6

STEP 7

STEP 8

STEP 9

STEP 10

STEP 11

STEP 12

COMPLETED