

ASSEMBLY INSTRUCTIONS

Read these instructions carefully. Refer to hardware and furniture parts list for guidance. Be sure all parts are complete, before assembling. Place all wooden furniture parts on a clean and flat soft surface to prevent scratches. Refer to steps provided as assembling guide.


CAUTIONS :

1. Do not **FULLY-TIGHTEN** the nuts or nut bolts until all are in place.
2. To prevent thread damage. Ensure that nuts or nut bolts are not over-tightened.
3. Hardware is to be kept out of reach of children.


PART LIST		
ITEM	DESCRIPTION	QTY
A	BACK REST	1 PC
B	SIDE LEG(L & R)	2 PCS
C	FRAME SEAT	1 PC
D	CUSHION SEAT	1 PC

HARDWARE LIST		
ITEM	DESCRIPTION	QTY
1	JCBC SCREW M6 x 25MM (BLK)	4 PCS
2	JCBC SCREW M6 x 80MM (BLK)	4 PCS
3	JCBC SCREW M6 x 50MM (BLK)	2 PCS
4	SPRING WASHER 1/4" (BLK)	10 PCS
5	BARREL NUT M6 x 13MM	4 PCS
6	PAN HEAD WOODEN SCREW M5 x 32MM	6 PCS
7	WOOD DOWEL DIA 8 x 30MM	8 PCS
8	ALLEN KEY M4(BALL SHAPE) LONG	1 PC
9	ADJUSTABLE SCREW	4 PCS


STEP 1 :



STEP 2 :



STEP 3 :



STEP 4 :

