

ASSEMBLY INSTRUCTIONS

Read these instructions carefully. Refer to hardware and furniture parts list for guidance. Be sure all parts are complete, before assembling. Place all wooden furniture parts on a clean and flat soft surface to prevent scratches. Refer to steps provided as assembling guide.


CAUTIONS :

1. Do not **FULLY-TIGHTEN** the nuts or nut bolts until all are in place.
2. To prevent thread damage. Ensure that nuts or nut bolts are not over-tightened.
3. Hardware is to be kept out of reach of children.


PART LIST		
ITEM	DESCRIPTION	QTY
A	CUSHION SEAT & BACK REST	1 PC
B	FRONT LEG	2 PCS
C	BACK LEG	2 PCS

HARDWARE LIST		
ITEM	DESCRIPTION	QTY
1	JCBC SCREW M6 x 30mm(BLK) 	2 PCS
2	JCBC SCREW M6 x 40mm(BLK) 	6 PCS
3	SPRING WASHER 1/4"(BLK) 	8 PCS
4	FLAT WASHER 1 / 4"(BLK) 	2 PCS
5	ALLEN KEY M4(BALL SHAPE)LONG 	1 PC
6	PAN HEAD WOOD SCREW M5x32mm 	2 PCS


STEP 1 :




STEP 2 :




STEP 3 :




STEP 4 :



STEP 5 :



STEP 6 :



COMPLETED CHAIR ASSEMBLY