





















CHILDREN STEP

Assembly Instructions




Assembly Instruction

1 X1 	2 X1 	3 X1 	4 X1 
5 X1 	6 X1 	7 X1 	8 X1 
9 X1 	10 X1 		
A x24 	B x24 	C x1 	D x2 
E x2 	F x2 	G x20 	


STEP 1 	STEP 2 
---	---

Assembly Instruction


STEP 3



STEP 4



STEP 5



STEP 6

