


HM9880

SPLIT GUIDE RAIL



1	2	3
X1	X1	X1

4	5	6
X1	X2	X1

7	8	9
X4	X4	X4

10	11	12
X4	X4	X2

C	C (5X50)	D (4X30)
X28	X16	X4

E (3.5X12)	F (4X20)	G
X32	X8	X4

H	I	J (6.3X50)
X4	X8	X8

K
X8

L
Wall Plug
X2

M
Wall Strap Holder
X2

N
Wall Strap
X1

O
Screw (4x35)
X2

P
Screw (3.5x16)
X2




E
X16



A
X8
B
X8



D
X4







J
X4

Step 5


Step 6

Step 7


Step 8



Step 9



Step 11



Step 12

